



## Farécla Shrimper Mid & End Season Topside Top-Up Instructions



### **Materials Required**

Profile 300 Rapid Cut & Surface Restorer  
Profile Polymer Wax  
Farécla Finishing Cloth  
*\*Farécla Industrial Polishing Machine*

*\*Double Sided Wool Pad*  
*\*14mm D/S Adapter*  
*\*Spurring Brush*

### **Step 1: Fresh Water Wash**

Wash topsides thoroughly with fresh water to remove all salt and dirt. This is an essential part of the process.

### **Step 2: Hull inspection**

Inspect the topsides for any obvious areas of surface bloom.

### **Step 3: Profile 300 Rapid Cut & Surface Restorer**

Remove any areas of surface bloom using Profile 300.  
Put a small quantity of compound on a soft cloth and apply to the areas of bloom, rubbing gently until the surface is clean and all bloom has been removed.  
Remove any compound residue using a Farécla Finishing Cloth.

*\*For speed and convenience, or larger areas of blooming, a Farécla Polishing Machine fitted with a double sided wool pad may be used for this step, but only if the boat is ashore. A polishing machine should **never** be used with the boat afloat.*

### **Step 4: Profile Polymer Wax**

Using a soft cloth spread a thin coat of Profile Polymer Wax onto the whole area of the topsides. Leave for around 30 seconds to haze then remove using a Farécla Finishing Cloth.